

COLLECTION
ARTHUR JUNGHANS

JUNGHANS UHREN GmbH · Postfach 100 · D-78701 Schramberg
www.junghans.de

42.712-0458 / 4303520 / 0507 J810.2

”BY THE WORK ONE KNOWS THE WORKMAN.”

Jean de la Fontaine

Congratulations on purchasing a timepiece from the 'Arthur Junghans' collection.

The models in this collection of watches are all exclusively fitted with mechanical movements, thus creating a link back to the company's origins. The look of today's collection picks up on the values of traditional watchmaking, giving these a contemporary interpretation.

Each model's glass base makes the intricate artistry of the top quality watchmaker's handiwork clearly visible. The movements are precision made and decorated in a special, traditional Junghans style. Given a stripe finish, they act as a reminder of the old masters.

We hope you will get great pleasure from this wonderful time-keeping instrument.

Yours,
Junghans Uhren GmbH

Contents

Instructions for use	13
Ambassador power reserve Calibre J810.2	14
General information	16

Page


Instructions for use

Winding up the watch

With the winder in the winding up position (position A), you can wind up the automatic movement manually. Just 2 or 3 turns are sufficient to start the movement going. It is better to wind it up fully, as this ensures that it will run with maximum accuracy and that its power reserve (even after the watch is put down) will last for the maximum period. If your model has a screw-locked winder, this must be unscrewed by turning it to the left to start your watch going. After you have set your watch, you should wear it, so that the automatic winding system (via rotor movement) keeps it constantly operational.

Features and functions

Calibre J810.2



Setting the time

Pull the winder into position C. That stops the watch movement. To set your watch accurately to the second, it is best to stop the movement as the second hand is passing the figure 60. You can now position the minute hand precisely in line with the relevant minute marker and set the desired time. Press the winder back into position A to start the second hand.

Setting the date

Pull the winder into position B. You can now set the date by turning it to the right. **Do not make any changes to the date between 8pm and 3am, as the date is automatically advanced by the movement during this period and you could damage the date advance mechanism.**

If the month has less than 31 days, you have to set the date manually to the first day of the following month.

Power reserve display

The power reserve display tells you how much time is left until the watch will stop.

Technical information

Mechanical 3-hand movement with date and power reserve display

Calibre J810.2

Automatic winding mechanism with ball-bearing

21 jewels

28,800 semi-vibrations per hour

Approx. 42 hour power reserve

Anti-magnetic to DIN 8309






Shockproof: Incabloc

Spring: Nivarox II

Balance: Gold-plated nickel

General information

Water resistance

Designation	User Information				
	 Washing, rain, splashes	 Showering	 Bathing	 Swimming	 Diving without equipment
no designation	no	no	no	no	no
3 ATM	yes	no	no	no	no
5 ATM	yes	no	yes	no	no
10 ATM	yes	yes	yes	yes	no

The designation "water resistant" only applies to brand new watches. External influences can affect water resistance. Please have your watch checked regularly.

- Service work, such as repairs to glass, seal or strap, should only be performed by a specialised dealer. We recommend that you contact a Junghans partner.

You can find a partner in your area at www.junghans.de

- In the event of condensation entering your watch, the watch should be examined by service center without delay. Water entering the watch may cause damage.
- Your watch is fitted with a high-quality strap that has been subjected to numerous tests at our company. Should you nonetheless wish to replace the strap, please use a strap of the same quality, ideally an original strap.
- Watches with leather straps should not be exposed to strong UV rays.
- Clean watch and strap with a dry or slightly damp cloth.
Note: Do not use chemical cleaning materials (e.g. petrol or paint thinners). These may damage the surface.