



Automatikwerk
Self-winding movement
J800.1.6

JUNGHANS – DIE DEUTSCHE UHR

Congratulations on becoming the owner of an original Junghans!

Junghans watches are and always have been something special. They have made watchmaking and design history. And we are still doing so today. For the story of success that began in 1861 in Schramberg in the Black Forest continues with each new model. Present in every watch are the elements that make Junghans special: style, passion, innovative spirit and precision right down to the tiniest detail. Put another way: when traditional craftsmanship, leading edge watch technology and classy design come together, then it is a genuine Junghans. A watch for all those who live their own style – and on that we can not do other than congratulate you!

Your

Uhrenfabrik Junghans GmbH & Co. KG

Contents

Instructions for use

General information

Page

15

19

Instructions for use


Important note:

Do not make any changes to the date between 08:00 p.m. and 02:00 a.m., as the date is automatically advanced by the movement during this period and you could damage the date advance mechanism.

Winding up the watch

With the winder in position A, you can wind up the automatic movement manually. At least 2 to 3 rotations of the winder are needed to start the movement. Maximum accuracy and maximum power reserve are ensured when the watch is fully wound (see technical information) – even after taking the watch off. After you have set your watch, you should wear it, so that the automatic winding system (via rotor movement) keeps it constantly operational.

Features and functions



- 1 Hour hand
- 2 Second hand
- 3 Date display
- 4 Minute hand
- 5 Winder

Setting the time

Pull the winder into position C. That stops the watch movement. To set your watch accurately to the second, it is best to stop the movement as the second hand is passing the figure 60. You can now position the minute hand in line with the relevant minute marker and set the desired time. Press the winder back into position A to start the second hand.

Setting the date






Pull the winder into position B. You can now set the date by turning it to the right. **Do not make any changes to the date between 8pm and 2am, as the date is automatically advanced by the movement during this period and you could damage the date advance mechanism.** If the month has less than 31 days, set the date manually to the first day of the following month.

Technical information

Calibre J800.1.6

- Automatic movement with display for date
- Bi-directional winding
- Fully wound: min. 27 crown rotations
- 28,800 semi-vibrations per hour
- 38 hour power reserve
- Anti-magnetic to DIN 8309
- Shockproof: Incabloc
- Balance: Gold-plated nickel

Water resistance

Marking	Instructions for use				
	 Washing, rain, splashes	 Shower	 Bath	 Swimming	 Diving without scuba tanks (snorkelling)
No mark	No	No	No	No	No
3 BAR	Yes	No	No	No	No
5 BAR	Yes	No	Yes	No	No
10 BAR	Yes	Yes	Yes	Yes	No
20 BAR	Yes	Yes	Yes	Yes	Yes
30 BAR	Yes	Yes	Yes	Yes	Yes

The water resistance as prescribed by DIN is a design engineering characteristic which is susceptible to external influences such as shock, fluctuations in temperature, UV light and direct contact with cosmetics and cleaning products (greases and acids). The “3–30 BAR” condition is thus only applicable for brand new watches. We recommend having the watch inspected at regular intervals.

General information

The water resistance of your watch can be affected by external influences, which can cause moisture to enter the watch. We therefore recommend regular checkups by a Junghans specialist. Servicing and bracelet repairs should also be carried out by an authorised Junghans service partner.

Please avoid direct contact with alcohol containing perfumes, disinfectants and chemical cleaning detergents (e.g. petrol or paint thinner), as this will shorten the life of the glass, gaskets and leather strap.

Your watch is equipped with a quality strap which has been tested inhouse several times. If you would like to change your strap please use a strap of the same quality, preferably an original strap. The watch and leather straps can be cleaned with a dry or slightly damp cloth. Metal bracelets should preferably be cleaned with a small brush and soapy water.

Live your style.



Uhrenfabrik Junghans GmbH & Co. KG
Geißhaldenstr. 49 · D-78713 Schramberg
www.junghans.de · info@junghans.de