



Automatikwerk
Self-winding movement
J880.3

Junghans. Live your style.

Congratulations on becoming the owner of an original Junghans!

Junghans watches are and always have been something special. They have made watchmaking and design history. And we are still doing so today. For the story of success that began in 1861 in Schramberg in the Black Forest continues with each new model. Present in every watch are the elements that make Junghans special: style, passion, innovative spirit and precision right down to the tiniest detail. Put another way: when traditional craftsmanship, leading edge watch technology and classy design come together, then it is a genuine Junghans. A watch for all those who live their own style – and on that we can not do other than congratulate you!

Your

Uhrenfabrik Junghans GmbH & Co. KG

Contents

Instructions for use

Page

17

Technical information

20

Instructions for use


Winding the watch

The automatic movement can be wound manually in crown position A. If your model has a screwed crown, it must be unscrewed by turning it anticlockwise.

A minimum of 2 to 3 rotations of the crown is required to actuate the movement. If the watch has not been worn for a long time and has therefore come to a standstill, you can wind it manually. It is fully wound up after approx. 60 rotations of the crown. Movement of the watch when worn on the wrist generates the necessary energy. When fully wound, maximum power reserve is guaranteed.

Features and functions

Calibre J880.3



Setting the time

Pull the crown to position B. This stops the movement. To set the watch accurately to the second it helps to stop the movement when the second hand is over the 60. You can now set the desired time. To achieve a time display that is as accurate as possible, we recommend subsequently positioning the minute hand in a backwards movement. This serves to minimise the degree of tolerance in the trains. Example: You wish to set the time as 10.10. Rotate the minute hand clockwise until

10.20 is displayed, then set the time of 10.10 in anticlockwise direction. Return the crown to position A to start the second hand.

- 1 Hour hand
- 2 Minute counter
- 3 Stop second counter
- 4 Minute hand
- 5 Start-stop pusher
- 6 Crown
- 7 Reset pusher
- 8 Second hand

Chronoscope functions

Initiating time measurement

Begin the chronoscope function by pressing the start-stop pusher (5).

Stopping time measurement:

Stop the chronoscope function by pressing the start-stop pusher (5) again.

Resetting:

Press the reset pusher (7). This resets both stopwatch hands to their zero position.

Addition time measurement:

Press the start-stop pusher (5) again after the respective measurement to add the stop times. The chronoscope hands will then recommence from the stopped position.

Technical information

Calibre J880.3

Automatic movement with chronoscope function


Bi-directional automatic winding mechanism

28,800 semi-vibrations per hour

Power reserve 42 hours (without chronoscope function)

Anti-magnetic as per DIN 8309

Water resistance

Marking	Instructions for use				
	 Washing, rain, splashes	 Shower	 Bath	 Swimming	 Diving without scuba tanks (snorkelling)
No mark	No	No	No	No	No
3 BAR	Yes	No	No	No	No
5 BAR	Yes	No	Yes	No	No
10 BAR	Yes	Yes	Yes	Yes	No
20 BAR	Yes	Yes	Yes	Yes	Yes

The water resistance as prescribed by DIN is a design engineering characteristic which is susceptible to external influences such as shock, fluctuations in temperature, UV light and direct contact with cosmetics and cleaning products (greases and acids). The “3–20 BAR” condition is thus only applicable for brand new watches. We recommend having the watch inspected at regular intervals.

General information

External influences can affect the watch's waterproof qualities, which may let in moisture. We therefore recommend that you have your watch regularly inspected by your Junghans specialist. Other servicing tasks or wrist strap repairs should also be done by your Junghans specialist. Your watch is fitted with a quality wrist strap that has undergone multiple inspections in our factory. If, however, you decide to change the strap, please fit a new one of the same quality, preferably an original Junghans wrist strap. Watch and wrist strap can be cleaned with a dry or slightly moistened cloth. NB: Do not use chemical cleaners (e.g. benzine or paint thinners). These may harm the surface.



Uhrenfabrik Junghans GmbH & Co. KG
Geißhaldenstr. 49 · D-78713 Schramberg
www.junghans.de · info@junghans.de